

## Q : How do I connect my Mobile Computer to my PC running Windows 2000/XP?

---

### WARNING

USING THIS SOLUTION COULD RESULT IN LOSS OF ALL DATA  
PLEASE PROCEED WITH CAUTION

#### Setup Requirements:

- A Motorola or Intermec Mobile Computer running Windows Mobile 5 or 6, or Windows CE Core or Professional 4.2 or 5
- A single-slot cradle suitable for your model of Mobile Computer.
- A power supply and the correct USB interface cable for your cradle (typically a Type B or Mini Type B ([See here](#)))
- A Desktop or Notebook PC running Microsoft Windows 2000 SP2 or later or Windows XP SP1 or later.
- An installation of Microsoft ActiveSync 4.5 ([Download here](#))

[\[How to find Model Number\]](#) [\[Determine OS Version\]](#)

#### Download Instructions:

No additional files are required to perform this operation.

#### Installation Instructions:

- Connect the power supply unit to the cradle and insert your device.
- If not already booted, wait for the device to complete booting.
- Connect the USB interface cable to the cradle and PC.
- Wait for ActiveSync to detect the connection (you will hear a sound).
- If you wish to synchronize items with Microsoft Outlook or another application, click *Next* on the pop-up window and complete the necessary configuration to set up the synchronization process (these settings can be changed at any time)
- If you are just going to transfer files or install an application, click *Cancel* on the pop-up window.
- You are now connected/synchronized.

If you require further information or have any questions please contact:

[techsupport@leopardsystems.com.au](mailto:techsupport@leopardsystems.com.au) or call 03 9534 2022 (Mon - Friday 9am - 5pm).